




Spare Parts List PPU0010





PARTS LIST			
OBJECT	QUANTIT Y	PART NUMBER	TITLE
1	1	PPU0200	PPU Mast Frame
2	4	VMS6x35	Machine Screw 6x35, DIN 931, A2
3	1	ELPPU0081	Drive
4	6	BU1218	Flange bushing 12x18
5	5	VSR12	Adjusting ring 12 mm
6	8	VM8S	Lock nut M8
7	2	VMS10x25	Hexagon head screw 10x25
8	4	VIZ6x130	M6 cylinder head screw
10	17	VM8	M8 nut
11	2	VM12S	Lock nut M12
12	1	VSO10x40	Lock screw M10x40
13	2	ELPPU0070	ELPPU0070
14	2	ZPF003	Key
15	2	PPU0110	Drive wheel
16	10	BU1222	Bearing bushing 12x22x30x20x4
17	2	VSC13x37	Washer 13x37 DIN9021
19	4	VIZ6x10	M6 cylinder head screw
20	3	VSC13x24	U-shaped washer 13x24
21	2	PPU0119	Sprocket
22	1	PPU113	Triple chainring
23	1	ELPPU0030-01	Shift lever
24	1	PPU0125	Spacer bushing
25	1	VSC10.5x20	Washer M10 DIN125
26	1	PPU0114	Chain wheel Tensioner pulley
27	1	VM10S	Lock nut M10
28	1	PPU0112-01	Chainwheel hub 12mm
29	1	PPU0020	Footboard for PPU mast
30	2	PPU0111-01	Swivel castor 80 mm
31	1	ELPPU0080	Planetary gear
32	1	ELPPU0031	Battery switch
33	1	PPU0202	Aluminum roller tubes 30x4
34	2	PPU0206	Small pick up roller, bottom 320 mm
35	1	PPU0207	Large pick up roller, top, 320 mm
36	3	PPU0210	Stainless steel threaded rod M8
38	1	PPU0122-01	Control



PARTS LIST			
ITEM	QUANTITY	PART NUMBER	TOPIC
1	2	ELPPU0014	IN4007 Zener Diode
2	1	ELPPU0090	Drive controller
3	3	ELPPU0010	24V, 30A Relay
4	3	ELPPU0041	3A fuse, purple
5	1	ELPPU042	20A fuse, yellow
6	1	PPU0156	PPU controller with Replaceable battery
6	1	PPU0122-01	PPU controller without Replaceable battery